

RECURVE BARE SHAFT TUNING


Note: spine adjustments are for right handed archers. Reverse for left handed archer

Multiple adjustments:

1. Raise nocking first
2. Make adjustments last

Stiff Spine:

1. Decrease button tension
2. Adjust centre shot. Move arrow towards bow
3. Increase bow poundage
4. Increase point weight



Weak Spine:

1. Increase button tension
2. Adjust centre shot. Move arrow away from bow
3. Decrease bow poundage
4. Decrease point weight